

HIKOKI

CORDLESS JIG SAW CJ18DB

Item No.	Code No.	Description	No. Used	Remarks
1	379152	MICRO SWITCH (B) SET	1	
2	379150	HOLDER PLATE	1	
3	372288	TAPPING SCREW (W/FLANGE) D3X12	3	
4	379490	SPRING	1	
5	375867	SLIDE KNOB (A)	1	
6	379143	SWITCH COVER	1	
7	333916	WASHER	1	
8	696352	TAPPING SCREW D3X6	1	
9	379153	SWITCH COVER ASS'Y	1	INCLUD.4-8
10	379142	HOUSING ASS'Y	1	INCLUD.11
11	379492	SUPPORT (B)	1	
12	379145	MOTOR	1	
13	930196	SUPPORT (B)	3	
14	379146	GUARD BAR (A)	1	
15	379144	SWITCH CONTROLLER ASS'Y	1	INCLUD.1
16	379151	DIAL	1	
17	379491	O-RING	1	
18	378683	BATTERY BSL 1850MA (EUROPE,AUS,NZL)	2	INCLUD.502
19	301653	TAPPING SCREW (W/FLANGE) D4X20 (BLACK)	8	
20		NAME PLATE	1	
21	376481	LEVER SPRING	1	
22	375856	LEVER	1	
23	333916	WASHER	1	
24	332929	TAPPING SCREW (W/FLANGE) D3X20	1	
25	376473	PLUNGER COVER	1	
26	325077	SEAL LOCK HEX. SOCKET HD. BOLT M3X6	2	
27	376476	SPRING (C)	1	
28	376475	SPRING PLATE	1	
29	376487	PLUNGER HOLDER (B)	1	
30	376474	PACKING	1	
31	376467	WASHER (A)	2	
32	376480	RETAINING RING D15	1	
33	376472	PLUNGER (B)	1	
34	376604	NEEDLE ROLLER (C)	1	
35	982454	SPRING (C)	2	
36	376479	PLUNGER PIECE	1	
37	376478	HOLDER SPRING	1	
38	376477	HOLDER COVER	1	
39	376470	PLUNGER HOLDER (A)	1	
40	376471	PLUNGER (A)	1	
41	332829	CONNECTING PIECE (A)	1	
42	325242	NEEDLE BEARING	1	
43	376466	GEAR	1	
44	376469	BALANCE WEIGHT	1	
45	376468	ORBITAL CAM	1	
46	376460	PIN D6	1	
47	377886	RETAINING RING D7	1	
48	377887	WASHER (A)	1	
49	377885	GEAR HOLDER ASS'Y	1	INCLUD.35,47,48,50-55
50	673489	RETAINING RING (E-TYPE) FOR D5 SHAFT	1	
51	376683	NEEDLE ROLLER D4X24	1	
52	335297	STEEL BALL 5/32 (10 PCS.)	1	
53	338992	CHANGE KNOB	1	

* ALTERNATIVE PARTS

* ALTERNATIVE PARTS

